

Zenith Chair Mechanism Instructions



Lever 1: Pull the lever upwards to release the back rest

Once you are comfortable with the back position, push the lever downwards to lock this position

Lever 2: Pull the lever upwards to alter the chair height up and down.

Lever 3: Pull the lever upwards to release the tilt mechanism. Once you are comfortable with the tilt of the chair, push the lever downwards to lock this position. If you would prefer the chair to be free flowing and remain in the rocking motion, leave the lever in the upwards position.



Front Lever: Pull the lever upwards to operate the seat slider mechanism.

Pulling the lever upwards will result in the forward slide of the chair seat. To move the seat backwards, pull the lever upwards (when chair is stationary) & slide the seat back.

Ratchet Back: A ratchet back enables you to be able to adjust the back height up and down.

To operate lift the back all the way to the top to release the mechanism, then drop all the way down. Once at the lowest point you can move the back in steps and lock in when at the height you require.